

EV3 Classoom:

Updating Your Software and Firmware

By Sanjay and Arvind Seshan




LESSON OBJECTIVES

- 1. Learn how to update the software
- 2. Learn how to update the firmware

WHY BOTHER WITH UPDATES?

- When you first receive your EV3, you should update both your EV3 software and brick firmware versions.
- Many users continue to run the default software and firmware versions.
- There have been important bug fixes and new features since the EV3 first came out.
 - For example, the VM Program Instruction Break error was resolved in the last update in 2016.




TO UPDATE YOUR SOFTWARE

- 1) Open the EV3 Programming Software you installed earlier
- 2) From the Menu, pick "About LEGO MINDSTORMS EV3"
- 3) A pop-up window will appear, showing the version of the software you are running
- 4) Click on the "Check for Update..." menu item to see if there is a newer version of the software

EV3 Classroom	File	Edit	View	Window	
About LEGO® MINDSTORMS® Education EV3 Classroom Check for Update					
Preferences					
Hide Hide Others Show All					НЖ НЖ <i>Г</i>
Quit					ЖQ






UPDATING BRICK FIRMWARE

The current EV3 Scratch software does not support updating brick firmware

To update firmware go to:

- https://ev3manager.education.lego.com/
- Download and Install EV3DeviceManager when prompted




© EV3Lessons.com, 2020, Last Update: (12/21/2019)

UPDATING BRICK FIRMWARE

Once the EV3DeviceManager is installed the Web page should show connected devices and firmware version

Note that this only works with usb connected bricks. You may need to refresh the page and/or disconnect+reconnect the brick after you install the software to see this screen

Click on the update firmware if needed



UPDATING BRICK FIRMWARE

Update available Update the brick now to improve stability and performance. Please make sure you have at least two bars of power on the brick before updating. Update now Later Updating... Do not remove the USB cable or close this application. Success! Your brick is now up to date! After your brick finishes starting, please turn your brick off and turn it back on. Done

You should see the dialog boxes on the left as part of the update process.

Follow the instructions given (e.g. click Update now)

At the end of the process, you will need to power cycle the brick to get it to connect to your computer



- This tutorial was created by Sanjay Seshan and Arvind Seshan
- More lessons are available at www.ev3lessons.com



This work is licensed under a <u>Creative Commons Attribution-</u> <u>NonCommercial-ShareAlike 4.0 International License</u>.

© EV3Lessons.com, 2020, Last Update: (12/21/2019)